



Clear and Simple Quick Start Guide



Getting to know your ZTE Blade™ X Max



Phone setup

1. With your phone powered off, insert the tray eject tool into the hole on the nano-SIM/microSDXC card tray and pull the tray out.
2. Place the nano-SIM and microSDXC cards in the tray with the gold-colored contacts facing down.
3. Carefully slide the tray back into place.
4. Charge your phone with the included charging adapter and USB Type-C cable.

Note: The battery and back cover are not removable. Removal could result in damage to the device and voided warranty.

WARNING! To avoid damage to the phone, do not use any other kind of SIM card or any non-standard nano-SIM card cut from a SIM card. You can get a standard nano-SIM card from your service provider.

Touch screen

- ### Navigating your phone
- Press and hold the screen to unlock.
 - Use your fingertip to lightly touch the screen.
 - Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
 - Spread two fingers apart or pinch them together on the screen to zoom in or out on a web page or Gallery image.
 - To return to the previous screen, tap the **Back key**.
 - Tap the **Home key** at any time to return to the main home screen. Press and hold the **Home key** to access Google Now™.
 - Tap the **Recent apps key** to access recently viewed apps.
 - Tap **Apps** to access applications on your phone.

Note: To exchange the positions of the Back key and Recent apps key, tap **Settings** > **Navigation key** and select an option.

- ### Notifications panel
- Drag your finger down from the top of any screen to see the Notifications panel.
 - Tap to access the full Settings menu.
 - Tap to add, move, or delete icons in the quick settings menu.
 - Swipe right or left to clear individual notifications, or tap **CLEAR ALL**.

Personalize

- ### Set wallpaper
- To change your home screen or lock screen wallpaper, press and hold a blank part of the home screen and tap **Wallpapers**.
 - Tap the lock screen or home screen preview, and then tap a wallpaper to set it. You can also tap **GALLERY** or **LIVE WALLPAPER** for more options.
- ### Add to home screen
- Tap **Apps**, press and hold the desired app, and drag it to the home screen.
 - Press and hold a blank part of the screen and tap **Widgets**. Press and hold the desired widget and drag it to the home screen.
 - Press and hold a blank part of the screen and tap **Themes** to change the theme or **Home** to manage the home screen panels.
 - Press and hold an icon to drag it to a new location. Drag it to **Remove** to delete it.
- ### Register your fingerprint
1. Tap **Apps** > **Settings** > **Security** > **Fingerprint**.
 2. Follow the steps to register your Fingerprint + Pattern, PIN, or Password.
 3. Tap **REGISTER**.
 4. Follow the instructions to record your fingerprint.
 5. Tap **OK**.

Calls and voicemail

- ### Make a call
1. From the home screen, tap **Phone**.
 2. Tap the search box at the top of the screen, or tap **Dialer** to open the dialpad. Enter a contact name or a phone number.
 3. Tap the matching contact or **Call** to place the call.
- ### Check voicemail
1. From the home screen, tap **Phone** > **Dialer**.
 2. Press and hold the **1 key**.
 3. If prompted, enter your voicemail password.
- ### Use call waiting
- Call waiting helps you answer or hold a call while you are on an existing call.
1. While on a call, you will hear a tone if another call comes in. Tap **Hold current and ans...**
 2. Tap **Merge** to merge calls or tap the other call to switch between active calls.

Note: To access phone settings, tap **Menu** > **Settings** from the main phone screen.

HD Voice Capable

Text and picture messaging

- ### Send a text message
1. From the home screen, tap **Messaging**.
 2. Tap **New message** to start a new text message.
 3. In the **To** field, enter a number or contact name, or tap **ALL CONTACTS** to select from your contacts.
 4. Tap the **Send message** field and enter your message.
 5. Tap **Send** to send the message.
- ### Send a picture message
1. Follow steps 1-4 above.
 2. Tap the **Paperclip**.
 3. Tap **Check** to snap a photo, or tap **Gallery** to select a photo from your gallery.
 4. Tap **Send** to send the message.

More information

On the web
Detailed support information, including device specifications and troubleshooting, is available at www.cricketwireless.com/support/devices.

On the phone
• Call Customer Care at **1-855-246-2461** or
• Dial **611** from your cell phone.

Accessories

For more information concerning accessories, please visit your local Cricket store location or go to www.cricketwireless.com/shop/accessories.



Note: Store and online inventories may vary.

Product meets FCC Radio Frequency Exposure Guidelines—FCC ID SRQ-2983. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) if this device must accept any interference received, including interference that may cause undesired operation.

© 2017 Cricket Wireless LLC. All rights reserved. Cricket and the Cricket logo are registered trademarks under license to Cricket Wireless LLC. Other marks are the property of their respective owners. microSDXC™ logo is a trademark of SD-3C, LLC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories. Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Used with permission.

© 2017 ZTE CORPORATION. All rights reserved. No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation. The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.


Email

Email setup (Gmail™, Yahoo!®, etc.)

1. From the home screen, tap **Apps** > **Email**.
2. Follow the steps to set up your account.

Create and send an email message

1. From the home screen, tap **Apps** > **Email**.
2. To compose a new message, tap **Compose**.
3. Tap the **To** field. Enter an email address, or tap **Add contact** > **Contacts** > **Groups** or **Recent callers** to select from your contacts.
4. Enter a subject and email message.
5. To attach files, tap **Paperclip** and choose the type of attachment you want.
6. Tap **Send** to send the message.



Cricket services

Cricket services
These services make using Cricket even better and easier.

- My Cricket:** Access billing, make a quick payment, view usage, and access support from the palm of your hand.
- Cricket Wi-Fi Manager:** Helps you save your high-speed data by seeking out free and open Wi-Fi® hotspots whenever you're near them. Also remembers your favorite Wi-Fi hotspots and connects you automatically. Cricket does the searching so you can do the saving.
- Visual Voicemail:** Quickly view, access, and play back your voicemail messages. Easily save important numbers to your **SAVED** list and respond to messages by calling back or texting.
- Deezer from Cricket:** Listen on-the-go with ad-free streaming music, download your favorites to your phone, and get customized playlists based on your preferences.

Cool tools

- Selfie:** Take selfies quickly and easily. Access the front-facing camera from either the lock screen or the Apps menu to instantly capture the moment.
- AskMD:** Consult with AskMD® about symptoms or health conditions, find a nearby physician, and organize your health information to prepare for more effective doctor visits.
- Dolby Audio:** Via headset or stereo speakers, Dolby Audio™ provides premium sound and customizable audio settings for music, movies, and gaming.
- Fingerprint Sensor:** Register up to five fingerprints to unlock your phone, quick-launch an app, take photos, or answer calls.
- Heart Rate Monitor:** Monitor and track your heart rate without any external hardware.

Apps on Google Play™

The Blade X Max is preloaded with great apps to take your experience to the next level. To find additional apps, check out Google Play.

- ### Access Google Play
1. From the home screen, tap **Play Store**.
 2. Enter your existing Google™ account or create one following the steps on the screen.
- ### Navigate Google Play
- From the Play Store, you have multiple ways to search for apps, games, and more.
1. Tap a category to browse apps, games, movies, and music organized by popularity or category.
 2. Tap the Google Play search bar to search the Play Store for a specific game or app.
 3. To install, tap the app and follow the instructions. Once installed, you will see a notification in the Notifications panel. Open the app from this notification or by locating it in **Apps**.



Camera and video

The Blade X Max lets you choose from four different modes (manual, panorama, multi exposure, and time-lapse video) to satisfy every type of photographer!

- ### Take a picture
1. From the home screen, tap **Camera**.
 2. Zoom in and out by pinching/spreading your fingers on the screen or by pressing the **Volume key**.
 3. Tap the **Shutter button** to take a photo.
 4. Tap **Settings** to adjust your camera settings.
- ### Take a video
1. In camera mode, tap **VIDEO** > **Start recording** to start, tap **Pause recording** to pause, tap **Resume recording** to resume, and tap **Stop recording** to stop recording video.
 2. Tap **Settings** to adjust your camcorder settings.



Health and fitness tracking

Argus is a healthy lifestyle services app that makes staying fit easy, painless, and fun! Argus provides activity and diet tracking along with a social network focused on health and fitness. You can also monitor and track your heart rate with Blade X Max's built-in heart rate monitor.

- ### Set up Argus
1. From the home screen, tap **Apps** > **Argus**.
 2. Tap **Enter Your Email**, or sign up via Facebook® or Google+™.
 3. To set up your profile, tap **Menu** > **Settings** and enter your height, weight, heart rate, stride length, and other specifics.
 4. Tap the blocks on the app's main screen to set up your calorie goals, add a buddy, read motivational tips and tricks, and more.

- ### Use Argus
1. From the home screen, tap **Apps** > **Argus**.
 2. Tap **Add** > **Activity** and choose an activity (Eat, Move, Workout, Sleep).
 3. Follow the on-screen instructions.

Notes:

- Activities you can track can be customized (e.g., Move/Workout). Select an activity, and then tap **START** > **CUSTOMIZE**.
- To pause and resume recording of an activity, tap **Pause** / **Resume**. Tap **Stop** > **Save** to save the activity.

